



Architect and Engineer Specification

MANUAL PULL

CATALOG
NUMBER
P.1.12.01-1



P/N 20-128



P/N 02-3710

Description

The Fike Fire Alarm Pull Station (02-3710) and Releasing Manual Pull Station (20-128) are high quality all metal units. The manual pull station uses a SPST switch connected to a terminal strip for quick field installation. The activation switch is a normally open contact rated for 2.5A, 120/250V that closes when the station is activated.

Operation

Raising the hinged outer cover and pulling down on the front cover operates the double action station. The hanging cover displays positive indication and may only be reset with the supplied key.

Mounting

Surface Mounting:

- Use mounting box with minimum 3/4" depth

Semi-Flush Mounting:

- Use standard back box

Manual Pull Sign (optional)

P/N	Size	Wording
02-10137	4"W x 2.25"H	HFC-227ea Extinguishing System Release

Place the optional sign (02-10137) adjacent to the Releasing Manual Pull Station.

P/N 02-3710 Fire Alarm Pull Station
UL- S4874
CSFM - 7150-1137:101

P/N 20-128 Releasing Manual Pull Station
UL- S6239
CSFM - 7150-1137:101

Replacement Key

P/N 02-10102

Specifications

Switch: SPST 2.5 Amp 120/250V

Nominal Size: 5"H x 3"W x 1"D

Color: Red (02-3710 has raised white lettering)

Engineering Specifications

Manual Station shall be of metal construction. Manual Stations shall be UL listed. The station shall be double action and activated by a pull on the front cover. When activated cover shall hang down to give visual indication of activation. A key shall be required to reset the station.

Labels for Releasing Manual Pull

The Releasing Manual Pull Station includes a set of three labels for field installation (labels should be placed on the face of the pull station between the Fike logo and the reset key):

Size: 2"W x 1"H

Wording: Water Mist
HFC-227ea
CO₂

July, 2002
Revised Issue

This page intentionally left blank